


The 'Print Day' at the end of day cuts before the complete report is printed.

Upon delivery, some receipt printers are set with a PAPER SIZE of 80 x 297 mm.


To change this, go into the Windows Control Panel to Devices and Printers.

There you should now see your printer.

Click with the right mouse button and select the Printer Properties




In the next window, go again to "Properties" and then to "Layout"



Here you can see the format of 80x297.

Click on "Custom size."

Modify the default "Custom Size" in such as "FGS" and change "width" to 80 and length to max. length = 3276.



First save the paper size and then press "ok"

The problem with overlong printing is resolved.

The screen shots were created in Windows 8th In other Windows versions can view differ slightly.