


**Example of a wireless connection from a Tablet PC with Win8 to one or more printers connected via LAN cable.** (In the trial modify the printer is not possible.)

Place the router in your premises, so you always have contact with the Tablet PC.

We recommend for a smooth transfer security, always connect the printer with LAN cables (up to 100 meters). If the tablet out of the wireless range, yet the receipts are sent to the printer the next time you connect.




The IP addresses can be changed

Enter the login information for your router (interface) and wireless key in the sketch.

Check before you start the FGS software if the printer be able to print the test page via the Windows control panel.



Click with the right mouse button and select the Printer Properties



Print a test page

The images were created in Windows 8 and may look different in other versions of Windows.

If the pressure of the test page successfully go to the FGS\_Restaurant program on "Admin \ Settings" and then to the button "Printer Port":

After selecting the individual printers for the various receipts, the window should look something like this:

**Printer Settings** Click on text or number = Edit!

	Expression	Printer	Paper (mm)	Cutter	Print Layout	Menu Language 1 or 2
	Beverage Order Form	EPSON_TM_Bar	79	<input checked="" type="checkbox"/>	English	1
	1. Kitchen Order Form	EPSON_TM_Kitchen	79	<input checked="" type="checkbox"/>	English	1
	2. Kitchen Order Form	EPSON_TM_Kitchen	79	<input checked="" type="checkbox"/>	English	1
	3. Kitchen Order Form	EPSON_TM_Kitchen	79	<input checked="" type="checkbox"/>	English	1
	Invoice - Receipt	EPSON_TM_Bar	79	<input checked="" type="checkbox"/>	English	1
	Print Day	EPSON_TM_Bar	79	<input checked="" type="checkbox"/>	English	1
	reprint Invoice (Admin)	EPSON_TM_Bar	79	<input checked="" type="checkbox"/>	English	1
	Reprint Invoice	EPSON_TM_Bar	79	<input checked="" type="checkbox"/>	English	1
	Petty Cash	EPSON_TM_Bar	79	<input checked="" type="checkbox"/>	English	1
	Customer order form	not print	79	<input checked="" type="checkbox"/>	English	1
▶	Cash Drawer	EPSON_TM_Bar		<input type="checkbox"/>	English	

More about the printer port, refer to the main description on the following page:

<http://www.fgs-ltd.com/en/restaurant/testversion.html>